

Pearl District 3-Way Assembly Instructions

- 1) Attach casters to bottom of frame base.
- 2) Slide frame upright over attachments and attach frame base using 2 screws, repeat for all four uprights.
 NOTE: Leave screws loose for adjustment
 DO NOT TIGHTEN.
- 3) Attach cross bar at top between uprights using 2 screws.
 NOTE: Leave screws loose for adjustment
 TIGHTEN WHEN COMPLETE.
- 4) Slide shelf into base frame, matching peg in base with hole in bottom of shelf.
- 5) Slide brackets into slots in uprights, position parallel, repeat as needed.
- 6) Slide hangbar or shelves over pegs in brackets until secure.
- 7) Slide peghooks and/or faceouts over hangbar and position as needed.
- 8) Slide sign holder into center slot in top crossbar, slide acrylic insert into slot in top of sign holder.

Includes:

- 2 - A Frame Uprights
- 1 - B Frame Crossbar
- 1 - C Frame Base
- 4 - D 3" Casters (2 locking)
- 16 - Screws (pkg.)

